



	CE1	CS	CS1	CS2	IC	OC
Codigos de recambio Spare codes	CE02	C22	C23	C11N	AZ3	CS970

	PT	R	T1	T2	CE2
Codigos de recambio Spare codes	PT21	R20	T925/04	T25A	CT8