



	CE1	CE2	CS1	CS2	CS3
Codigos de recambio Spare codes	CE02	CE812RF	C30	C16	C11N

	IC	OC	PT	R	T
Codigos de recambio Spare codes	DK3	CS811	PT20	R35	T812/97