



	CE1	CE2	CE3	CR	CS1	IC
<b>Codigos de recambio</b> <b>Spare codes</b>	CE25B	CE02	CE25A	C22	C30	AZ3

	OC	PT1	PT2	R	RA	T	TM
<b>Codigos de recambio</b> <b>Spare codes</b>	CS13	PT25	PT21	R20	RA22	T922	CT5