



	CE1	CE2	CE3	CR	CS1	CS2	IC
Codigos de recambio Spare codes	CE25B	CE02	CE25A	C22	C930	C11N	AZ3

	OC	PT1	R	RA	T	TM
Codigos de recambio Spare codes	CS970	PT21	R20	RA22	T925	CT4