



	CE1	CR	CS1	CS2	IC	OC
<b>Codigos de recambio</b> <b>Spare codes</b>	CE02	C22	C23	C11N	AZ3	CS970

	PT	R	T1	T2	TM
<b>Codigos de recambio</b> <b>Spare codes</b>	PT21	R20	T925/04	T25A	CT7