

FERVE F-2400

BATTERY AND ALTERNATOR TESTER

12 V - 24 V



12 V	%	
< 11.9	< 20%	POOR
12.1	25%	FAIR
12.3	50%	FAIR
12.5	75%	FAIR
12.7	100%	FULL



Fully illustrated
instruction manual


FERVE F-2400

THE MOST PRACTICAL TESTER



FOR ALL, FOR ALL
batteries users

TWO TYPES OF CONNECTION:


Lighter socket




Directly to the battery



Liquid batteries:
Lead-acid, silver calcium



Gel batteries:
VRLA, AGM



Alternators:
12 V and 24 V

